



mouNTEK

Meet the nGroove Snap,
from Mountek.



THANKS FOR PURCHASING NGROOVE
SNAP BY MOUNTEK! NGROOVE SNAP IS A
REVOLUTIONARY NEW APPROACH TO THE
MOBILE DEVICE MOUNT, WITH A SLEEK
NGROOVE BLADE THAT EASILY WEDGES
INTO CD SLOTS AND DASHBOARD SEAMS.

Introduction	1
Precautions	2
CD Slot Installation	4
Dashboard Seam Installation	7
Magnetic Adapter Installation	10
Additional Uses	12

Just wedge, tighten and drive!

nGroove Snap's adjustable and magnetic mount works with any device, anywhere, from Garmin to iPhone, Samsung, Galaxy Nexus 7, Galaxy Tab 7", Motorola, HTC, Droid, Blackberry, Nook, iPad mini, and Nokia devices. nGroove Snap's pre-assembled blade has made car mount installation simple and effortless. Forget suction cups, clips, screws, and adhesives. No more sticky stains or residue on your dashboard.

Please read through the following instruction sheet before using nGroove Snap. If you have any issues or questions, please don't hesitate to contact us at SUPPORT@MOUNTEK.ZENDESK.COM. We aim to develop products that beat our customers' expectations. Any feedback you provide to our support group will be forwarded to our development team and evaluated for future designs.



TABLET USERS

The nGroove Snap as packaged is not recommended for full size tablets, such as the iPad or Galaxy Tab 10.

Smaller tablets, including the iPad Mini or Nexus 7, may be suitable for use with the nGroove Snap.

However, direct metal-to-magnet contact is highly recommended. Before attempting to mount a tablet, ensure that the nGroove Snap is firmly installed into your vehicle's CD player slot or dashboard groove.

WARNING

Expand the nGroove blade by slowly turning the tightening wheel. Stop once the nGroove Snap holds securely. Do not overtighten. You must completely loosen the nGroove blade's tightening wheel before uninstalling the mount. Failure to comply may cause permanent damage to your CD slot or vehicle.

CD Slot Installation

All car stereos are made differently. If nGroove Snap does not hold securely after installation, it is likely that the nGroove blade is not compatible with your vehicle's CD slot.



Completely loosen the tightening screw, so the nGroove blade is in a closed position.



Insert the nGroove blade into your vehicle's CD slot and turn the tightening screw clockwise. The blade will slowly expand. Stop once the nGroove Snap holds securely. The nGroove Snap should not move after installation, but do not overtighten. Failure to comply may cause permanent damage to your stereo.

CD Slot Installation

CONT'D



Attach the magnetic adapter to the 17mm ball joint and snap your device into place, then freely tilt the device for the best viewing angle.

Dashboard Seam Installation



Remove the detachable center blade by rotating the connecting pin until both the dot on the pin and the dot on the mount are facing the same direction, then removing it as shown.

Dashboard Seam Installation CONT'D

2



Firmly insert the nGroove blade into any tight seam or groove in the dashboard.

3



Attach the magnetic adapter to the 17mm ball joint and snap your device into place, then freely tilt the device for the best viewing angle.

Magnetic Adapter Installation

1



Peel the adhesive protector off of the metal badge and stick it to the back of your device or device case. Note that the badge will also provide a firm hold if you place it between the back of the device and your device case, to hide the badge for a completely invisible look .

2



Place the back of your device onto the magnetic adapter to snap the device into place.

Additional Uses

No CD slot or dashboard? Use nGroove Snap as a portable stand wherever you need your mobile device.



DESKTOP STAND – Easily use your device while you work on your desktop. Open the nGroove Snap blades to firmly mount your device on any desk, table, or flat surface. If mounting a full size tablet, place the badge in direct contact with the magnetic adapter instead of placing it underneath a tablet case.



TRIPOD – Easily mount your device on tripods for a firm, adjustable hold. Remove detachable center blade by removing the connecting pin as shown, then use the 2nd hole for mounting onto a tripod.



mouuntek



Visit [MOUNTEK.COM](https://www.mouuntek.com) for alternate installation techniques, or [MOUNTEK.ZENDESK.COM](https://www.mouuntek.com/help) for more tips and tricks.